

VOLA Electronic

Elektronikboks

Valve box

Ventil Kasten

Ventilbox


Ventiel doos

Boite étanche avec vanne




EU EMC directive
2004/108/EU
IPX4

VR2618



VR2617



www.vola.com

mnt_Elektronikbox_V10_40999840
17-03-2022

© VOLA A/S




vola

Settings: Einstellung:	Setting: Justering:	Afstelling: Réglage:			
	Sec.	1	2	3	4
DEFAULT SETTING:		ON	ON	ON	ON
ON	0	ON	ON	ON	ON = 20 sec. - hygienic rinse every 24h. - hygienische spülung jede 24 stunde. - hygiejneskyl 24t efter sidste brug. - hygienisk skölja varje 24 timmar. - hygiénisch spoelen iedere 24 uur. - Rinçage hygiénique chaque 24h.
OFF	3	ON	OFF	ON	
	5	ON	OFF	OFF	
	8	OFF	ON	ON	
	10	OFF	ON	OFF	
	15	OFF	OFF	ON	
	20	OFF	OFF	OFF	
SPECIAL: Long spout Lange Auslauf Langt udløb Långt utlopp Lange uitloop Long bec	*0	ON	ON	OFF	


installation requirements:
Installationsanforderungen:

Sunlight or light from halogen lamps can shorten the signal range.
Sonnenlicht oder Licht von Halogenlampen können das Signal verkürzen.
Skarpt sollys eller halogenlys, kan forkorte rækkevidden.
Starkt sollys eller halogenbelysning kan förkorta signalen/känsligheten.
Directe lichtinval van de zon of van halogeen lampen kan het signaal verkorten.
La lumière du soleil ou des lampes à halogène peut perturber le fonctionnement du détecteur.




Krav til installation:
Installationskrav:

No mirroring surfaces opposite the sensor.
Keine spiegelnden Flächen vor dem Sensor.
Ingen reflekterende overflader modsat sensoren.
Inga speglade ytor motsatta sensorn.
Geen spiegelen oppervlakken tegenover de sensor.
Pas de surfaces réfléchissantes opposées du capteur.



Adapter/ Adapteur VR2624 & VR2636



DC Power supply
DC Stromversorgung
DC strømforsyning
DC Nätaggregat

VR2622: ROW & GB
VR2626: EU
VR2623, IPX5:
VR2622/VR2626:

110 - 230V~/50-60Hz
9V~/300 mA
100 - 240V~/50-60Hz/130mA
9V~/660 mA
VR2623, IP64:

DC voeding
Alimentation électrique


VR2622-VR2623-VR2626
VR2624-VR2636:
 To be ordered separately
 Separat bestellen
 Bestilles særskilt
 Beställas separat
 Apart te bestellen
 À commander séparément

Battery operation
Batteriebetrieb
Batteridrift
Batterij bedrijf
Fonctionnement sur batterie


2 x 1.5V AA - FR6 - FR6

Batteries **MUST be removed if operated by Power supply.**
Batterien **MÜSSEN bei Stromversorgung entfernt werden.**
Batterierne **SKAL fjernes ved brug af strømforsyning.**
Batterier **SKAL tas bort om der anvendes nätaggregat.**
Batterijen **MOETEN worden verwijderd als ze op netvoeding werken.**
Les piles **DOIVENT être impérativement retirées si on utilise l'alimentation électrique.**

VR2618




Adjustment of sensor range.
Einstellen von Reichweite des Sensors.
Justering af sensorafstand.
Justering av sensoravstånd.
Instellen van de sensor-afstand.
Réglage sensibilité de capteur.
Standard: ca. 15 cm.




Installation examples Installationsbeispiele

Fig. 1



Installationseksempler Installationsexemplar

Fig. 2



Installatie voorbeelden l'installation des exemples

Fig. 3




Fig. 4 Ceiling mounted
Deckenmontage
Loftmonteret

Takmonterad
Plafondmontage
Monté au plafond





Fig. 5




Wiring diagram Schaltplan

4000/4100/4300
4800/4900

Ledningsdiagram kopplingschema

Aansluitschema Schéma de câblage



Sheet:
SB21.16