


VOLA HV1, HV3, HV4

Fitting instruction
Montageanleitung
Monteringsvejledning
Monteringsvægledning
Montage hanleiding
Manuel de montage



HV1, HV3:
04/00295
04/00300










www.vola.com

HV1/HV3/HV4_V6_40999827
13-11-2023



HV1, HV3	L	H	h
Std.:	114 mm 4 1/2"	120 mm 4 3/4"	27 mm 1"
+30:	114 mm 4 1/2"	150 mm 6"	56 mm 2 1/4"
/150:	150 mm 6"	120 mm 4 3/4"	27 mm 1"
+30/150:	150 mm 6"	150 mm 6"	56 mm 2 1/4"
+170:	114 mm 4 1/2"	290 mm 11 1/2"	197 mm 7 3/4"
+170/150:	150 mm 6"	290 mm 11 1/2"	197 mm 7 3/4"





5



Data, 3 Bar/43.5 Psi:

	Max.	l/min.	Gal/min.	Note.
HV1/3:	5.0	1.3		Standard
HV1/3:	4.5	1.2		Standard USA
HV1/3:	9.0	1.8		Standard Japan
HV4	9,0	1.8		

 Max. 70°C, 158°F




HV1






HV3




HV4






HV4: Ø10
 HV4JP: Ø10
 HV4US: Ø3/8"
 HV4Q: Ø3/8"



VR277K: VR22, VR269, VR277
 VR010Z: VR623, VR624Z
 VR297: VR20, VR22, VR269, VR273, VR277, VR294, VR295, VR296
 VR433: VR261, VR263, VR440, VR442, 2xVR444
 NR.10: VR20, VR22, VR293, VR294, VR295



vola
 Lunavej 2
 DK-8700 Horsens
 Tlf : + 45 7023 5500
 sales@vola.com
 www.vola.com

HV4 Family:

HV4, HV4L, HV4M

Date
 Jan. 23

Rev.
 7

Sheet
 SB 24.1